

STC-04 OUTSIDE AIR DAMPER, MODULATING

Outside air damper is open when supply fan is running. Mixes recirculated air with outside air.