

STZ-01-S-... HUMIDITY OR AIR QUALITY SENSOR, ZONES

Humidity or air quality sensor

The sensor can the zone and thus the unit or be used for monitoring. Also the sensor can control modulating dampers.

STZ-01-S-06-1	Air quality sensor (CO ₂), room sensor
STZ-01-S-06-2	Air quality sensor (CO ₂), air duct sensor
STZ-01-S-09-1	Humidity sensor, room sensor
STZ-01-S-09-2	Humidity sensor, air duct sensor